



GameNetic User Manual



GN90002_28082020





3

Install the Product

Overview Product

3





3

Check Interactive Elements

Control the Volume and Test

4




5

The 4 games

Install and Manage a Timelock

6



7



Maintenance



Install the Product
 Install the product according to the Playnetic Installation Manual. During the installation, make sure that the potential users can not be exposed to hazards / dangerous situations. Check the stability of the product.



Number of Users
 Playnetic recommends you to use the product with a maximum of one user at a time.

Overview Product
 The overview above shows where all important parts can be found.





Check Interactive Elements
 Use the product and generate energy. If applicable, check that the interactive elements such as the music, lights, smell, electronic- and mechanical parts are working properly.





Control the Volume

1. Remove the bolts with the supplied hex key.
2. Remove the service hatch with the label.
3. Generate energy with the product.
4. Adjust the volume.
5. Close the service hatch.



Volume




Play and Test

1. Press the foot pedal to generate energy with the product.
2. Test if all the games can be played properly.
3. Test if the lights, music and display work.




*Are the tests incorrect? Then you should contact your local dealer.



The 4 Games



1. Quick Sums Quiz

Test your math skills with the Quick Sums Quiz! 3 times 4 is? The GameNetic displays 2 answers on the left and right of the display. Press the left or right button to answer!




2. Speed Test

How fast can you press the buttons? Use your speed and do your best to get the highest score.




3. Quick Colors

The GameNetic says Blue! Yellow! Not purple! And you must press the right button. How far can you get?



4. Memory

Use the push buttons and foot pedal to play these games. Remember the correct order. Red, foot, blue! Now you repeat. The difficulty keeps increasing.






Receive Time Lock

1. Receive a USB device. Playnetic has set the correct start- and endtime for you.



Install and Manage a Time lock

1. Remove the bolts with the supplied hex key.
2. Remove the service hatch.
3. **Important! The time lock must be installed at 12 o'clock local time. If the install is being done too late or too early, the time lock will not work properly.**
4. Put the USB stick into the computer.
5. Generate energy. Wait until the update is completed. Remove the USB stick after completion.
6. Make sure that you put the dust cover back over the USB port.
7. Close the service hatch.



Maintenance

The product must be maintained according to the Playnetic Maintenance Advice.

